

# NEXEN

## SMART ADAPTOR INDEPTH SETUP GUIDE



A ONE-STOP  
SMART HOME  
SOLUTION

NEXEN


AN INTEGRATED POWER  
& LIGHTING SOLUTION  
DESIGNED FOR ANY  
SMART HOME ECOSYSTEM

EVERYDAY ELEVATED




## HOW TO SETUP SMARTLIFE APP


# NEXEN SMART ADAPTOR




1 Download the **Smartlife** App from Google Play Apps or from the Apple App Store



2 Sign up for an account in the Smart Life App



3 Give permission for the Smart Life App to access your Bluetooth and Home Data




4 Make sure your mobile phone is connected only to the 2.4 GHz Wifi Connection

## HOW TO SETUP SMARTLIFE APP


# NEXEN SMART ADAPTOR




5 When the Smart adaptor is initially activated "ON", it is not connected to the 2.4 GHz Wifi Network, hence the adaptor LED Light will be blinking continuously to show it is in pairing mode.



6 Go to the front screen of the Smart Life App and click on **"Add Device"**




7 The Discovering devices window will pop-up and please click on **"Add"**




8 You will need to enter your 2.4GHz Wifi Connection Password

## HOW TO SETUP SMARTLIFE APP


# NEXEN SMART ADAPTOR




9 The "Add Device" window with the progress bar will pop-up



10 Once device is added, it will appear in your Home Screen. Click on the device to edit it.




11 Click on the Device Name to edit it.




12 Click on the Device Title to edit the name in the Device Properties Menu

## HOW TO SETUP SMARTLIFE APP


# NEXEN SMART ADAPTOR




13 Click on the Device Name to edit it.



14 Input the New Device Name



15 In the main display menu, you will see the Power ON button which you can use to Activate **On** or **Off** your Nexen smart adaptor using 2.4GHz Wi-Fi




16 You can also set schedules to automatically Activate **On** or **Off** your Nexen smart adaptor




HOW TO SETUP SMARTLIFE APP

# NEXEN SMART ADAPTOR



17 You can set vary the days and timing to set different schedules to automatically Activate **On** or **Off** your Nexen Smart Adaptor.



18 You can also monitor the power consumption of the device plugged into your Nexen Smart Adaptor.




19 If there are any problems with the smart adaptor connection, reset the adaptor by turning it ON and off consecutively 3 times to reset it.


Once the adaptor is reseted, it will go into blinking mode and you can reconnect to it

HOW TO SETUP SMARTLIFE APP

# NEXEN SMART ADAPTOR




1 Tap on **"Me"** and click on **"Home Management"**



2 Click on **"Create a home"**




3 Enter in your **"Home"** Location Address




4 Enter the **"Home Name"** and also select the rooms that exist in the Home. You can also click on **"Add Room"** to add in custom Rooms. Finally click on **"Save"** to save your Home settings

HOW TO SETUP SMARTLIFE APP


# NEXEN SMART ADAPTOR




5 Once you have saved your home settings, you will see the **"Home Name"** reflected in **"Home Management"**.



6 Click on **"Home Name"** and then click on **"Add Member"**




7 You can choose from a number of methods to add members to your **"Home"**.




8 If you use the 1st Method **"App Account"**, you will need to enter the **"Member's Name"** and his Smartlife Account Email Address


# NEXEN SMART ADAPTOR




1 Download the **Google Home** App from Google Play Apps or from the Apple App Store



2 Allow **Google Home** to find and connect to devices on your local network




3 Give **Google Home** access to your Google account to sign in




4 Once you have logged into Google Home using your Google Account, click on the **"Create Another Home"** and **"Next"**


# NEXEN SMART ADAPTOR




5 Enter your **"Home Nickname"** and click on **"Next"**



6 Enter your Home Address and Postal Code




7 Click on the **"Next"** after entering all the Address information.




8 Click on **"Next"** to grant Google Home Location Access

HOW TO SETUP GOOGLE HOME


# NEXEN SMART ADAPTOR




9 Click on "Allow While Using App" to grant Location Access.



10 Once you have signed into Google Home, this will be the Home Interface.




11 Click on the "Devices" and Click on "+ Add".




12 Click on "Works With Google"

HOW TO SETUP GOOGLE HOME


# NEXEN SMART ADAPTOR




13 Within the Add devices row, please enter "Smart Life"



14 The **Smart Life** App option appear and please click on this




15 Please click on "Agree and Link" to link your **Smart Life** Account with **Google**




16 You will see that "Account linked successfully" notification once the linking process is complete

# NEXEN SMART ADAPTOR



17 The **"Choose device"** window will pop-up automatically. Click on the **"Device Name"** and Click **"Next"**.




18 Choose the **"Home Address"** to add the Device to and click **"Next"**.


# NEXEN SMART ADAPTOR



21 Click and Hold for 2-3 seconds on the Device Name to enter into the **"Setting Window"**. You can tap the middle button to **"ON/OFF"** the Nexen Smart Adaptor




19 Click on the **"Exact Location"** and then click on **"Next"**.




20 You will see the device added within your chosen **"Home Address"** and categorized under the selected **"Location"**


# HOW TO SETUP GOOGLE HOME (SCENE CONTROL) NEXEN SMART ADAPTOR




1 On your Google Home Page, click on **"Automations"**



2 On the **"Automations"** page, you will see a list of **"Routines"**. In this manual, we will click on **"Leaving Home"**




3 On the **"Leaving Home"** page, you will see a list of **"Actions"** listed, scroll down the list




4 At the bottom of the list, click on **"Add Action"**


# HOW TO SETUP GOOGLE HOME (SCENE CONTROL) NEXEN SMART ADAPTOR




5 Click on **"Adjust Home devices"**



6 The list of connected **Home Devices** will be reflected and in this manual, we will select **Nexen Showroom Smart Plug 1**.





7 Please click on **"Turn on or off"** and select **"Off"** and click on **"Add Action"**




8 You will see that the action to **"Turn off"** **"Nexen Showroom Smart Plug 1"** is reflected and click on **Add action** to save it to the routine

# NEXEN SMART ADAPTOR




1 Download the Amazon Alexa App from Google Play Apps or from the Apple App Store

2 Give Permission for Amazon Alexa to Use Bluetooth




3 Sign into your Amazon Account




4 After Signing in, you will arrive at the Amazon Alexa App Homepage. Once that is done, activate your Smart Life App

# NEXEN SMART ADAPTOR




5 On the "Me" page of the Smartlife App, Click On Alexa



6 Sign in with your Amazon Account





7 Link your Smart Life Account to Alexa



8 Once your Smart Life Account is linked with Alexa, a notification message will appear



HOW TO SETUP AMAZON ALEXA

# NEXEN SMART ADAPTOR



9 Return back to your **Alexa** App and you will see new devices connected to **Alexa**.

10 Go to "**Devices**" page, Click on "**Add New Favourite**"





11 Click on "**Add Favorites**" to enter the list of devices that can be added.

12 Your Nexen Smart Adaptors will appear in the list and click on the star button to add to your list of favorite devices to access.



HOW TO SETUP AMAZON ALEXA (SCENE CONTROL)

# NEXEN SMART ADAPTOR



1 Go to "**More**" Page and click on Routines

2 A List of Default Routines will Appear. In this manual ,we will select on the "**I am Home**" routine




3 Click on "**Add another Action**"


4 The "**Add New**" Page will appear and click on "**Smart Home**"

HOW TO SETUP AMAZON ALEXA (SCENE CONTROL)

# NEXEN SMART ADAPTOR



5 Click On "All Devices"



6 Select your Nexen Smart Adaptor from the list




7 A list of Action Variables will appear and in this manual, we will click on "Power"




8 2 Options will appear, namely "On" and "Off". Select "On" and click "Next"

HOW TO SETUP AMAZON ALEXA (SCENE CONTROL)

# NEXEN SMART ADAPTOR



9 The new action will be saved in the Routine page and click on "Finish" Button to save the Routine



10 With the new routine, when you say the keywords "Alexa I am Home", the Nexen Smart Adaptor will "Power On" automatically.

# IMPORTED SAFETY INFORMATION

- This user guide contains important product operating instructions, safety and maintenance information
- Please read this user guide before use

 Keep away from fire  Not for outdoor use

 Keep away from water

## CARE AND MAINTENANCE

- The product is to be used and stored a room temperature (-5°C to 40°C, not exceeding an average of more than 25°(in any 24 hours period)
- Keep the device dry.
- Do not store the product in dirty, dusty areas.
- Do not expose the product to rough handling
- Do not use harsh chemicals, cleaning solvents or strong detergents to clean.
- Disengage the product from the track when not in use

**\*Please read through this guide before using the adaptor. Any damage resulting from improper usage of the product will not be covered by our Product Warranty\***

## NEXEN SERIES ADAPTOR SPECIFICATIONS

Parameter	Nexen Series
Rated Voltage	250VAC
Rated Current	13 Amp
Frequency	50Hz/ 60Hz
Size (Dia x Depth)	67 X 43mm
Weight	78 grams
Degree of Protection	Ordinary
Warranty	3 Year, subject to Warranty T C

**\*Visit [www.nexenlife.com](http://www.nexenlife.com) to find out more on our Product Warranty T&C\***

# NEXEN

EVERYDAY ELEVATED

## SMART ADAPTOR USER MANUAL

**\*Nexen Smart Adaptor needs to be connected to the 2.4GHz Wi-Fi network before reading this manual\***

## NEXEN Adaptor- Switch On Guide



**1** Align the adaptor's rotary axis to insert into the middle groove part of the track.



**2** Insert the adaptor to the bottom of the power track. At the 9'o Clock Direction, the adaptor is turned "**OFF**".



**3** Turn the adaptor fully 90 degrees clockwise to the 12'o Clock Direction until you hear the "**Click**" sound




**4** At the 12'o Clock Direction, the adaptor is turned "**ON**"

## NEXEN Adaptor- Switch Off Guide



1

At the 12'o Clock Direction, the adaptor is turned **"ON"**



2

Turn the adaptor fully 90 degrees anti-clockwise to the 9'o Clock Direction until you hear the **"Click"** sound



3

At the 9'o Clock Direction, the adaptor is turned **"OFF"**

## NEXEN Adaptor- Slide Left/Right Guide



4

When the adaptor is turned fully at the 9'o'Clock direction, you can slide the adaptor to the **left** or **right**

## NEXEN Adaptor- Sliding Guide



**1** When the adaptor is turned fully at the 12'o Clock direction, the adaptor is locked and cannot be slide to the left or right of the e- ar



**2** When the adaptor is turned partially at the 10 to 11' o Clock direction, the adaptor is still locked. Please note **NOT TO** slide the adaptor left or right.



**3** Turn the adaptor fully to the 9'o Clock direction




**4** When the adaptor is turned fully at the 9'o'Clock direction, you can slide the adaptor to the left or right.

## NEXEN Adaptor- Standby Guide



**1** At the 12'o Clock Direction, the adaptor is turned "ON"



**2** To put the adaptor in standby mode, turn the adaptor slightly anti-clockwise until the 10 to 11'o Clock Direction



**3** At the 10 to 11'o Clock Direction, electricity is cut off and the adaptor is in standby mode



**4** At the "Standby" mode, the adaptor is locked and cannot be pulled out from the power track

